

Using the Cap Sealer



By adjusting the height and the cap size rollers you get the tool to fit your cap with the large roller at the bottom resting against the cap skirt. Turning the tool around the cap you are able to pean over the bottom of the cap so that it grips below the glass bead. When the end user unscrews the cap it should break at the joint between the cap and retaining ring.

